The DX Store

No BS. Just good old fas hioned Customer Service

DX-35CP - DX-65CP - DX-130CP Counterpoise



- 1. Connect ring terminal on jumper to the screw on the bottom of the HFJ-350M
- 2. Determine operating frequency and calculate 1/4 wave length
- 3. Un-spool approximately 1/4 wave length of wire based on your operating frequency (234/Frequency in Mhz) and stretch the wire out from the radio along the ground or from a table or other operating position to a tree, bush fence etc. Length is approximate and will have to be adjusted until desired results are achieved.
- 4. Attach the alligator clip to the DX-xxCP at the spool and leave the spool of excess wire next to the radio.
- 5. Enjoy.

Note: DO NOT touch counterpoise or let counterpoise touch the radio while transmitting.



866-899-DXIS (3947) - www.dxstore.com